

FITTING INSTRUCTIONS FOR RANGE ROVER SPORT SUPER OEM+ RUBBER STEPS



Do NOT remove or cut the plastic sills in any way

1. The chassis fixing holes are pre-drilled and threaded by the factory. The threaded holes are covered by removable plastic bungs running along the edge of sill. The rearmost bung and the second bung from the front on each side are used, so remove these bungs by pulling down sharply on the edge of the plastic sill.
2. Attach the brackets (DRIVERS SIDE FIRST) with bolts provided. **DO NOT FULLY TIGHTEN ANY BOLTS AT THIS STAGE.** Use a washer under each nut. The rear bracket outer fixing holes are sandwiched between the plastic sill and the body fixing. The inner leg fixings at the rear locate into holes in the chassis using the anchor bolt supplied. The front inner leg clamps around the gearbox tube (running front to back).
3. Now fit both passenger side legs. The passenger side rear bracket has to slide in past the air pump, the front passenger side bracket has to slide past the air tank and both should fit like the drivers side brackets when correctly located.
4. Locate steps into position on brackets, then fit M8 bolts. Rear 2 bolts first. Push steps in against the body of vehicle. Adjust steps for best fit and FULLY tighten all nuts and bolts.

